


2 The Parts of the System

THE SATELLITE DISH



The satellite dish collects the signals transmitted from the satellite. A coaxial cable carries these signals to the receiver, where they are decoded and processed so you can watch satellite television programming.

For installation procedures, see the *Installation Instructions*. For more detailed installation procedures, see the *Installation Kit Guide* included in the optional Installation Kit.

THE RECEIVER

THE RECEIVER FRONT PANEL



POWER LIGHT

This green light on the receiver front panel, lights up when the receiver is turned ON, and turns off when the receiver is turned OFF.



SMART CARD SLOT


The Smart Card should already be inserted in the receiver front panel slot, behind the door.



CONTROL BUTTONS

These receiver front panel buttons allow you to control the receiver. For information on using these buttons, see *Chapter 3 - Using the System*.

THE RECEIVER BACK PANEL



The back panel of the receiver provides the connectors that you use to wire the receiver to all the other electronic devices that you use. It also provides the receiver power cord and telephone jack. Depending on the wiring setup that you use, you may not use some of these connectors, but they are provided to support any desired setup. See *Chapter 4 - Reference* or the guide included in the optional *Installation Kit* for more information.

THE REMOTE CONTROL

Note: The Remote Control is shown below. For information on using the remote control, see *Chapter 3 - Using the System*.




If you lose or damage the remote control you will *not* be fully able to control the receiver. If this happens, call Customer Service at 1-800-333-3474 to order a replacement.

You will be charged the sale price of the remote control, plus shipping and handling.

Satellite System User Guide

THE MENU STRUCTURE

The following diagram shows the general structure of the higher level menus that the receiver displays on the television screen. These menus are described on the next few pages. Chapter 3 - *Using the System* explains, in more detail, how to use these and all of the associated sub-level menus to operate the satellite system.



The Parts of the System

2

MAIN MENU

The **Main** menu is the key to the menu structure. Each option on this menu displays another menu.




MAIL MENU

The **Mail** menu allows you to read electronic mail messages that may be sent via the satellite signal to the receiver.




PROGRAM GUIDE

The **Program Guide** provides a complete listing of the available channels and programs.




FAVORITES LISTS MENU

The **Favorites Lists** menu allows you to create, modify, and activate lists of favorite channels.




THEME CATEGORIES MENU

The **Theme Categories** menu allows you to choose programs based on the theme of their contents.



PARENTAL AND SYSTEM LOCKS MENU

The **Parental and System Locks** menu allows you to set and use security locks.



Satellite System User Guide

SYSTEM SETUP MENU


The **System Setup** menu provides a number of functions that help you set up and maintain the system.



THE BROWSE BANNER

You can use the **Browse Banner** to change channels or to see what other programs are available without changing the current program. Because the **Browse Banner** is transparent, using it will not block out the program you are viewing.

Note: If the ALL CHAN Favorites List is active, the **Browse Banner** displays all the channels. If another list is active, the **Browse Banner** displays *only* the channels on that list.



EVENT TIMER MANAGEMENT MENU

The **Event Timer Management** menu allows you to create an Automatic or Manual Event Timer or to Edit an Event Timer



DOLBY DIGITAL MENU

The **Dolby Digital Setup** menu allows you to listen to surround sound when viewing appropriately encoded satellite broadcasts.

